



Jensen JTA-230 Turntable Platter Replacement

This guide will take you through the steps of replacing the turntable platter.

Written By: Robert Wilcox





TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Turntable Platter




- Remove Cover from record player.

Step 2



- Remove the 4 rubber plugs which hold the turntable platter in place
- Gently but firmly pull the turntable platter off the axle.

Step 3



- Take replacement turntable platter affix it firmly and gently to the axle.

Step 4



- Replace rubber plugs

Step 5



- Replace Cover

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 06:51:33 PM.